

Chimney Option



1



Locate and prepare to assemble chimney sections.

2



Secure corners of chimney using two (2) 1¼" black headed screws per side.

3



Complete chimney assembly.

4



Carefully lift chimney to the roof. Measure inward 6" from end of roof and set chimney in place.

5



Secure chimney to roof using two (2) 2½" screws along base of chimney on both sides.