Little Cottage Co.

Loft Assembly manual Copyright 2005 lcc



Place two pieces of loft beside each other.



Slide loft pieces together and fasten with screws in front. Make sure loft pieces are tight together or loft may not fit in house.



Turn loft around and fasten with screws from either side.



Add a 36" 2*3 brace to the front bottom of loft. Use plenty of screws.



Add a 36" 2*3 brace to the back Bottom of the loft.

Loft assembly (cont)



Install the two loft bottoms. This is what the loft will rest on. Install the slanted edge toward the front. From the top of the 2*3 to the floor it should measure $42\frac{1}{4}$ inches.



Install the loft bottom or main piece, this slides on top of the loft bottoms. Fasten this with screws. Make sure it is secure.



Install left and right railing. Note how it is fastened on the inside of the 2*6.



Install the ladder. Put screws in the top and bottom by the floor. Make sure everything is fastened securely before using.