

CRS™ Wall SETUP

Note: Find Center Cutout of Each Wall to Begin



Step 1 Turn Up Corner Valance
Tip: Set leg height adjustment to lower level



Step 2 Find wall center CUTOUT and wrap outside of each corner leg.



Step 3 Locate frame wire, straddle wall cutout and begin clipping from middle
Tip: Attaching clips should face outward



Step 4 Continue clipping all the remaining hook fasteners until wall is fully suspended



Suspended CRS™ Wall



Decor to Your Preference!

More Detail www.GetCRS.com

