

Thank you for choosing Sunnydaze Decor. We stand behind our brand and the quality of the items we sell. Replacement parts or products will be sent at our discretion within the 1-year warranty period. Proof of purchase, with the date of purchase as well as photos of the merchandise defect, must be provided. Photos are used to determine the cause of defects and for future quality control. Register your warranty at <https://tiny.cc/SunnydazeWarranty>. If you have any questions, comments or concerns, feel free to contact us by phone at 833-982-1977, by email: [customerservice@sunnydazedecor.com](mailto:customerservice@sunnydazedecor.com), or via our contact us page at <https://tiny.cc/SunnydazeContact>










# FLORAL RESIN WALL UMBRELLA BASE LR-422


Read the assembly instructions carefully and follow the care instructions. Save this document for future reference.  
**Assemble on a soft, clean surface to avoid scratching or damaging the finish.**



Inspect packaging to ensure all parts are accounted for before disposing of packing materials.

To prevent small parts from being lost during shipping, the washers and bolt are loosely attached to the bottom of Pole (B). The threaded knob may be inside the pole, beneath the adapters.

No.	PARTS	QTY.
A	 Base (style may vary)	1
B	 Pole	1
C1	 Top Adapter	1
C2	 Middle Adapter	1
C3	 Bottom Adapter	1
D	 Threaded Knob	1
E	 Flat Washer	1
F	 Split Washer	1
G	 65mm Bolt	1



## ASSEMBLY

- Place Split Washer (F) and Flat Washer (E) onto Bolt (G) and insert through the bottom of Base (A).
- Attach Pole (B) to Base (A).
- Screw Threaded Knob (D) into Pole (B).
- Insert Adapters (C1, C2, C3) into the pole. Adjust adapters as necessary to fit your umbrella.

If Pole (B) feels loose, secure it more firmly by holding the pole and tightening the bolt with a wrench (not included). Do not over-tighten the bolt as it may strip the bolt and damage the product.

## ! SAFETY STATEMENTS & WARNINGS !

- Check for, and empty, standing water from the base.
- Do not stand on the base — it is only meant to support the weight of an umbrella.
- Store in a dry location when not in use — do not leave exposed to inclement weather.
- Clean with mild soap and water — use of harsh chemicals may damage the product and void the product warranty.
- Do not over-tighten the threaded knob as it may damage your umbrella pole.
- Close patio umbrellas when not in use and remove umbrellas during high-wind conditions; the base is designed only to support an umbrella and will not protect your umbrella from wind damage.

**Any modification to the product or failure to follow recommended care will void the product warranty.**

## ! WARNING:

Manufacturer and seller expressly disclaim any and all liability from personal injury, property damage or loss, whether direct or indirect, or incidental, resulting from the incorrect attachment, improper use, inadequate maintenance, or neglect of this product.